




international 4128

43401



4487 Scherenstromabnehmer

4487 Pantograph




4128-15 Stromabnehmerplatte

4128-15 Pantograph plate



4130-61 Schraube

4130-61 Screw



4128-01A Gehäuse komplett, grün

4128-01B Gehäuse komplett, rot

4128-01C Gehäuse komplett, braun

4130-25 Isolator-Gruppe

4134-45 Isolator


4128-01A Body assembly, green

4128-01B Body assembly, red

4128-01C Body assembly, brown

4130-25 Insulator group

4134-45 Insulator



4128-06 Geländer

4128-06 Handrails


4128-07 Vorbaudeckel

4128-07 Front lids




4130-31 Schaltkontakt

4130-31 Switch contact




4132-77 Feder

4132-77 Spring




4128-22 Schaltbolzen

4128-22 Switch pin




4128-20 Kontaktplatte

4128-20 Printed circuit, complete



4128-14 Hauptgewicht

4128-14 Main weight



4128



international

43401

4128-02 Achslagerrahmen

4128-02 Axle bearing frame

4458 Standardkupplung

4474 Kupplung, passend zu Fleischmann

4458 Standard coupler

4474 Coupler fitting with Fleischmann

4128-03 Stütze

4128-03 Coupler support

4128-13 Schraube

4128-13 Screw

0917 Motor komplett

0914-12A Bürste komplett

0917-14 Bürstenfeder

0917 Motor assembly

0914-12A Brush assembly

0917-14 Brush spring

4128-08 Rad-Kontakt

4128-08 Wheel-wiper

4130-63 Schraube

4130-63 Screw

5160-20 Motorboden

5160-23 Kontakt

5160-20 Motor base

5160-23 Base contact

4128-10A Radsatz komplett

4128-10A Wheel set assembly

